

Leroy G. Flamm

EPROM Burner Changes

Replace VPP switch with Center off type

