

BLUE RAM OWNER'S MANUAL

---

PERKINS ENGINEERING  
1004 Pleasant Avenue  
Boone City, MI 49712  
(616) 582-9832

Copyright 1982

This Page Intentionally Left Blank

## BLUE RAM OPERATIONS.

GENERAL. The BLUE RAM contains the following features:

1. 16384 (16K) bytes of read-write random access memory (RAM) which can be write protected either manually or under program control. This memory is in addition to the 4096 (4K) bytes of screen RAM built into the Arcade. The memory expansion option adds another 16384 bytes for a total of 32768 (32K) bytes of RAM. This memory is located at  $\%(-24576)$  or 6000 (hex). Note that ASTROBASIC treats negative memory addresses as references to screen memory making it impossible to access more than the first 8K of BLUE RAM memory using that cartridge. Use BLUE RAM BASIC for full memory access.
2. 128 bytes of additional scratch pad memory which cannot be protected from write operations. This memory is located at  $\%(-24576)$  or A000 (hex) in a 16K BLUE RAM and at  $\%(-8192)$  or E000 (hex) in a 32K BLUE RAM. Note that ASTROBASIC treats negative memory addresses as references to screen memory making it impossible to access this BLUE RAM memory area using that cartridge. Use BLUE RAM BASIC for full memory access.
3. A RANGE switch to allocate the first 8192 (8K) bytes of RAM to either 6000 (hex) for normal use or 2000 (hex) for game cartridge emulation. In the latter position the RAM acts as if it were a cartridge plugged into the front of the Arcade and running a machine-code program.
4. Two eight-line bi-directional I/O ports (PORT A and PORT B) where any line or combination of lines ~~may~~ in either port may be assigned as input or output lines under program control. I/O lines may be reconfigured at will under program control, by operating several control registers within the BLUE RAM.
5. External power and ground (+5V and 0V) available for powering additional low power (<0.5A) applications. The internal power supply has thermal protection against overloads which results in the temporary loss of power should an overload exist.
6. Special ports available for AUDIO-MIX, CPU CLOCK, I/O OPERATION SYNC, and I/O WAIT SYNC for expansion to (future) devices such as floppy disks and voice synthesis.
7. All external connections to the BLUE RAM are made via a 24 pin zero-insertion-force (ZIF) socket for easy access. This type of socket can accommodate 24 pin plugs, component leads, and bare wire ends directly without risk of bending.
8. 2 2000 BAUD tape ports for use with BLUE RAM BASIC. One port (MIC) is used for saving programs and data using BLUE RAM BASIC. The other port (EAR) is used to reload programs and data saved using BLUE RAM BASIC. These ports operate only in conjunction with BLUE RAM BASIC. Use the tape interface Jack (on the cartridge or tape interface) when operating with ASTROBASIC or BALLY BASIC.

## INSTALLATION PROCEDURE.

1. Locate the long rectangular "knock-out" on the back center of the Arcade case. Using a small screwdriver or knife, carefully remove this knock-out ensuring that you do not poke the screwdriver or knife into the case more than 1/4 inch.
2. The 50 pin PC connector exposed in the previous step may have its access blocked or interfered with by a portion of the insulating "fish paper" just below the circuit board. If this is the case, the portion which blocks access to the full depth of the connector must be removed. The easiest method of accomplishing this task is to use a very sharp Exacto knife to cut slots in the fish paper at the edges of the access hole, and bend it out of the way. Be sure to cut downward (away from the PC board) to prevent damage to the circuitry. An alternate method involves removing the upper case part, loosening the board, and cutting the fish paper with scissors.
3. Push the BLUE RAM 50 pin edge connector all the way onto the PC board connector until a firm stop is felt. Connect the small plug on the power module cord into the the small (front) jack on the BLUE RAM and plug the power module itself into a suitable 120V receptacle. Turn on the Arcade and depress RESET. This completes the installation procedure.
4. If you are using BLUE RAM (super extended) BASIC 1.1 in conjunction with the BLUE RAM, ensure that all switches on the BLUE RAM are in their back-most (6K-RAM AUTO LOAD) position, insert BLUE RAM (super extended) BASIC 1.1 into the cartridge slot, and depress RESET again. "BLUE RAM BASIC 1.1" should be displayed at the top of the screen in dark blue on a light blue background. This verifies proper installation.
5. The BLUE RAM contains non-volatile (static) memory and the contents may be preserved by leaving it plugged in. It will draw less than 5 watts of power when not in use and may be left in this "standby" condition, even with the Arcade turned off.

### WARNING!

Ensure that the power module cord plug remains plugged fully into the BLUE RAM! FAILURE OF THE POWER MODULE MAY OCCUR IF THAT PLUG SLIPS PART WAY OUT OF THE JACK!

### CAUTION!


Do not remove the BLUE RAM from the Arcade by pulling on the cable! Apply removal pressure directly to the edge connector either by prying from the sides with a small screwdriver or by removing the Arcade case and pushing directly on the edge connector.

SWITCH SETTINGS. There are three switches on the BLUE RAM for control of memory range, memory write protection, and the 2000 BAUD tape interface.

**RANGE SWITCH:** The RANGE switch is used to allocate BLUE RAM memory to a particular starting location or address and has two positions. The 6K-RAM position is the normal position for this switch and allocates the starting address of BLUE RAM memory to 24576 (or 6000 hex). For example, PRINT %(24576) prints the contents of the first word of BLUE RAM memory. (Note that the line number of the first line of a BLUE RAM BASIC program normally occupies this word.) The 2K-CASS position of the RANGE switch allocates the first 8K of memory so that it displaces the cartridge (if any) which is plugged into the cassette slot on the front of the Arcade. The only use of this position is to emulate a game cartridge by running a machine-code program similar to those in the regular game cartridges. Future issues of the ARCADIAN will explore this feature further. Also, see the CUSTOMIZE A GAME CARTRIDGE feature of the BLUE RAM UTILITY.

**MODE SWITCH:** The mode switch is used to control memory protection and has three positions. The AUTO position is the normal position for this switch and allows memory protection to be controlled by a program. (See %(64) and %(192) in the INPUT/OUTPUT section) The RAM (center) position disables memory write protection even if it was enabled by a program. Similarly, the RDM position prevents all writing to memory, except scratch-pad memory, regardless of any program instructions to the contrary.

**TAPE SWITCH:** The TAPE switch controls the 2000 BAUD tape interface and has two positions. The LOAD position is the normal position of this switch and allows 2000 BAUD programs previously saved using BLUE RAM BASIC to be loaded back into the BLUE RAM using the same BLUE RAM BASIC. With the TAPE switch in this position, line 0 of PORT B is internally connected to the tape interface and may not be used for other devices. However, with the TAPE switch in this position, 2000 BAUD tapes may be duplicated by playing the master tape from one recorder using the EAR connection, while recording the duplicate on another recorder using the MIC connection. The 2000 BAUD interface will control the record level and wave shape of the duplicate, offering enhanced data fidelity in many cases. The SAVE position is used in conjunction with BLUE RAM BASIC to save programs and data on tape at 2000 BAUD. This switch position is also used when it is necessary to use line 0 of PORT B for other than tape input. The TAPE indicator light is permanently connected to line 0 of PORT B and may thus be lit under program control. For example, %(163)=1;%(152)=0 will light the TAPE light when the TAPE switch is in the SAVE position.



Decimal address	BLUE RAM MEMORY MAP	Hexidecimal address	
24576	LOWER 8K	6000	
32767		7FFF	- highest address which can be accessed by ASTROBASIC or BALLY BASIC
-32768	SECOND 8K	8000	
-24577		9FFF	
-24576	SCRATCH-PAD FOR 16K SIZE	A000	
-24449		A07F	
	SECOND 16K		
-8193		DFFF	
-8192	SCRATCH-PAD FOR 32K SIZE	E000	
-8065		E07F	

## USING THE BLUE RAM WITH ASTROBASIC OR BALLY BASIC.

EXTENDED STRINGS. Of the many ways to use the BLUE RAM in conjunction with with ASTROBASIC or BALLY BASIC, probably the easiest is in the form of extended strings. As you are aware, either of these BASICs will access up to 900 string entries (with no program) using the @(<n>) symbol. If you write a 1000 byte program (SZ=800) then only 400 string entries are available. However, with the BLUE RAM 8256 string entries (16448 for 32K option) are always available, regardless of the size of your BASIC program. What's more, these string entries do not "move around" or otherwise change when you modify your BASIC program or load another program. This makes these special BLUE RAM string entries valuable for passing large quantities of data between programs.

The BLUE RAM extended string entries are accessed using the  $\%(2n+24576)$  form to "poke" and "peek" values into the extended strings. String entry #0 therefore, is at  $\%(24576)$  (since  $2 \times 0 + 24576 = 24576$ ), string entry #1 is at  $\%(24578)$ , #2 is at  $\%(24580)$ , etc. The MODE switch should be in either the RAM or AUTO position with RAM enabled. Performing a  $\&(192)=0$  will enable RAM mode in the AUTO position. Try this short example:


```
10 FOR N=1 TO 25           25 count loop
20  $\%(2 \times N + 24576) = N$   stores string # in string
30 NEXT N                 completes loop
40 FOR M=1 TO 25           another 25 count loop
50 PRINT  $\%(2 \times M + 24576)$  prints string content
60 NEXT M                 completes loop
```

You will note that each of the first 25 string entries were set to their own string number. Note also that the  $2x$  term provides 2 bytes (one word) for each string entry. A more efficient way of writing the same program is:

```
10 N=1:FOR A=24578 TO 24626 STEP 2: $\%(A) = N$ :N=N+1:NEXT A
20 FOR M=24578 TO 24626 STEP 2:PRINT  $\%(M)$ :NEXT M
```

A program will always be more efficient if the programmer does the math ( $2 \times 1 + 24576 = 24578$  and  $2 \times 25 + 24576 = 24626$ ) and uses the results as the values in the program statements so that the computer does not have to calculate those values over and over again when the program is running.

INPUT/OUTPUT. The BLUE RAM contains two 8-line bi-directional I/O ports. The first 8 lines are referred to as port A while the second 8 lines are referred to as port B. Either port may be configured with any line or combination of lines being in the INPUT mode (for receiving signals) or the OUTPUT mode (for sending signals). The following diagram shows the location of each line of each port on the 24 pin ZIF socket:



PIN	FUNCTION	PIN	FUNCTION
1	Ground return for PORT A	13	Ground return for PORT B
2	Line 7 of PORT A	14	Line 7 of PORT B
3	Line 6 of PORT A	15	Line 6 of PORT B
4	Line 5 of PORT A	16	Line 5 of PORT B
5	Line 4 of PORT A	17	Line 4 of PORT B
6	Line 3 of PORT A	18	Line 3 of PORT B
7	Line 2 of PORT A	19	Line 2 of PORT B
8	Line 1 of PORT A	20	Line 1 of PORT B
9	Line 0 of PORT A	21	Line 0 of PORT B*
10	+5v source for PORT A	22	+5v source for PORT B
11	Z80 CLOCK for external sync	23	WAIT(N) for external sync
12	AUDIO-MIX to add or tap sound	24	IOREQ(N) for external sync

\*Also connected to 2000 BAUD tape interface monitor light and is held at 0v when the TAPE switch is in the LOAD position. Place the TAPE switch in the SAVE position to use the line (with indicator) for other purposes.

The audio mixer (AUD) port accepts and/or provides a 1000 ohm +/- 2v audio signal to be mixed with or extracted from the Arcade sound system. This port may be used to extract sound such as a tape recorder voice-track or a voice synthesizer. The CLK, -WT, and -IO signals are connected directly to the Z80 microprocessor (pins 6, 24, and 20 respectively) and will be used for circuit synchronization in future BLUE RAM add-ons such as disk drives, etc.



Program control of the I/O ports is accomplished in BASIC via the  $\&(n)$  term where  $n$  is an I/O port number from the following table:

READ $x=\&(n)$	WRITE $\&(n)=x$	FUNCTION									
	162	Configures PORT A lines to be INPUT lines or OUTPUT lines according to the value written to $\&(162)$ . Each line is an INPUT line unless it is programmed as an OUTPUT line by setting its corresponding bit value into $\&(162)$ :  <div style="text-align: center;"> <table> <tr> <td>line 0 = 1</td> <td>line 1 = 2</td> <td>line 2 = 4</td> </tr> <tr> <td>line 3 = 8</td> <td>line 4 = 16</td> <td>line 5 = 32</td> </tr> <tr> <td>line 6 = 64</td> <td>line 7 = 128</td> <td></td> </tr> </table> </div> Example: To allocate PORT A lines 0, 1, 5, and 7 as OUTPUT lines - $\&(162)=1+2+32+128$ or $\&(162)=163$	line 0 = 1	line 1 = 2	line 2 = 4	line 3 = 8	line 4 = 16	line 5 = 32	line 6 = 64	line 7 = 128	
line 0 = 1	line 1 = 2	line 2 = 4									
line 3 = 8	line 4 = 16	line 5 = 32									
line 6 = 64	line 7 = 128										
	163	Configures PORT B lines to be INPUT lines or OUTPUT lines according to the value written to $\&(163)$ as with $\&(162)$ above.									
160	160	Accesses PORT A for data transfers to and from devices connected to PORT A. INPUT lines held high ( $>0.6v$ ) during a read operation result in their corresponding bit value being read from $\&(160)$ . A write operation to $\&(160)$ causes the corresponding OUTPUT lines to be set as indicated by the value written to $\&(160)$ . Example: To set all even OUTPUT lines of PORT A high ( $>3.2v$ ) - $\&(160)=1+4+16+64$ or $\&(160)=85$ . To verify this - PRINT $\&(160)$ NOTE: Outputs may read back as inputs.									
161	161	Accesses PORT B for data transfers to and from devices connected to PORT B as with $\&(160)$ above.									
128	128	Accesses line 0 of PORT A individually. If line 0 is held high during a read operation, a value of 128 is read; otherwise the value is 0. If line 0 of PORT A is allocated as an OUTPUT line, any value written to $\&(128)$ will cause line 0 of PORT A to be reset low ( $<0.6v$ ) without affecting any other line.									
129 thru 135	129 thru 135	Same as $\&(128)$ except that it applies to lines 1 through 7 of PORT A respectively.									
136 thru 143	136 thru 143	Same as $\&(128)$ except that it applies to lines 0 through 7 of PORT B respectively.									
144	144	Same as $\&(128)$ except that any value written to $\&(144)$ will cause line 0 of PORT A to be set high ( $>3.2v$ ) without affecting any other line.									
145 thru 151	145 thru 151	Same as $\&(144)$ except that it applies to lines 1 through 7 of PORT A respectively.									

READ x=&(n)	WRITE &(n)=x	FUNCTION
152 thru 159	152 thru 159	Same as &(144) except that it applies to lines 0 through 7 of PORT B respectively.
	164	A write operation to &(164) sets the overall operating mode of the I/O lines of PORT A and PORT B. Writing a value of 0 allows independent operation of all lines of both ports. This is the normal mode placed in effect by a RESET switch depression on the Arcade. &(164)=32 causes the strobed input mode to be activated whereby PORT A input data is latched as line 7 of PORT B goes low. Line 6 of PORT B (OUTPUT) is brought low until the program reads PORT A, indicating that the INPUT data is being held in the BLUE RAM. &(164)=96 causes the strobed output mode to be activated whereby line 6 of PORT B (OUTPUT) is brought low to indicate new data has been written to PORT A and is waiting for the device to accept it. The device brings line 7 of PORT B low to indicate that it has accepted the PORT A OUTPUT data and that the next output may now be written to PORT A. &(164)=224 causes a mode to be activated which is similar to &(164)=96 except that the OUTPUT data on PORT A lines only appears while line 7 of PORT B is held low by the external device. &(164)=0 resets the mode to independent operation of all port lines.
64	64	Any operation with &(64) sets the memory mode to ROM when the MODE switch is in the AUTO position.
192	192	Any operation with &(192) sets the memory mode to RAM when the MODE switch is in the AUTO position.

NOTE: Output lines will only supply 2ma. of current. Do not expect them to drive heavy loads. Use small relays or other amplifiers where more power is required.

WARNING! WARNING! WARNING! WARNING! WARNING! WARNING! WARNING! WARNING!

Do NOT connect A.C. appliances directly to the BLUE RAM I/O PORTS!  
NEVER CONNECT POWER FROM A 120V SOCKET DIRECTLY TO ANY PART OF YOUR  
ARCADE OR THE BLUE RAM OR SEVERE DAMAGE AND SHOCK HAZARD WILL RESULT!!!  
Relays or optical isolators with at least 1500v isolation should be  
used for controlling 120v A.C. appliances.