



BOX 94801
SCHAUMBURG, IL 60193

Wavemakers games are designed to run on your Astrocade Professional Arcade, using the Astrocade Computer Programming Cartridge, your cassette recorder and a standard phone cable with * $\frac{1}{8}$ " miniature connector.

Before using the software, be sure to insert the Astrocade Basic 6004 cartridge into your arcade and connect your recorder to the cartridge by inserting the * $\frac{1}{8}$ " miniature plug into the socket in the lower right hand corner of the basic cartridge and the other end into the ear-phone socket on the cassette recorder.

1. Press RESET.
2. Put the Wavemakers Tape into your cassette player and rewind fully. Set the recorder to full volume and tone, if you have one, to high or treble.
3. Place keypad overlay in position.
4. Enter **:INPUT;RUN** and press **GO**.
5. Press PLAY on your recorder. As the program loads you will see Wavemakers name and the name of the program. When the program is completely loaded it will run automatically.
6. Follow game instructions on reverse side.

TROUBLESHOOTING

A clean picture should appear on your screen as the program loads. There should be no holes in the letters or spots on the background.

If your tape doesn't load properly or if the program stops with a question and a line of the program:

- A. **REWIND THE TAPE.** Make sure the recorder is playing the program by pulling out the * $\frac{1}{8}$ " jack from the earphone socket of your recorder. You should hear a loud high pitched whistle. Reinsert the plug and adjust the volume to the point where the L.E.D. glows bright and steady. Rewind the tape and repeat steps 1 thru 5 of operating instructions.
- B. If your L.E.D. glows brightly but nothing appears on the screen, check all connections to be sure they are secure, eject and reinsert the basic cartridge. Repeat steps 1 thru 5.
- C. If after pressing the keys, the T.V. screen does not read **:INPUT;RUN** remove the overlay and key in **(. + = 203 = ! C)** in that order.
- D. If the screen does not read **:INPUT;RUN** something may be wrong with the arcade.